

Scorekeeper Specs, Parts & Assembly Instructions



Scorekeeper Parts & Specs

- 1 - 6 ft upright (1.5" diameter black powder coated aluminum)
- 1 - 36" top crossbar
- 3 - 14" middle crossbars
- 2 - Double sided 17"W x 9"H name cards made of 1/16" styrene (one full color that includes home team logo and one with "Visitor" in one color on white background)
- 48 - double-sided 6"W x 8"H scorecards made of .040" styrene (six sets of eight cards numbered 0-7)
- 10 - screws
- 2 - foam strips (used in the bottom of each of the two name card slots to secure name cards)
- 2 - diameter hose clamps (two per scorekeeper)
- Total weight of assembled scorekeeper frame - 7.5 lbs

Assembly Instructions

- Slide each of the three 14" middle crossbars onto the 60" upright and attach, using two screws on each middle crossbar
- Slide 36" top crossbar onto the 60" upright, using two screws
- Attach and secure upright to net post with two hose clamps after the scorekeeper frame has been fully assembled. For maximum support, position one hose clamp at the bottom third of the net post and one hose clamp at the top third of the net post. Exact positioning can vary slightly depending on your preference for the total height of the scorekeeper.
- Place one screw through hole on top bar and secure each name card with wing nut on opposite side of top bar. Add foam strips to fill in space between name card and top bar.
- Insert scorecards into six scorecard slots.
- Attach main post to net post (or umpire chair) with two hose clamps.

Tools Required

Small Phillips head screwdriver (tightening screws on scorekeeper frame)